

# INSTABAND ECO

Thermoplastic Overbanding

## INSTALLATION GUIDE



The crack in the pavement must be less than 5mm wide and 20mm deep.



1. Clean application area thoroughly by removing all sand, dirt, chemicals and oil substances.



2. Remove all moisture present (if any) in the surface and down the cracks with a gas burner.

In low temperatures, place the roll of Instaband on the surface and warm slightly, this will help to unravel the roll without breaking.



3. Place the Instaband material on the road surface with the beaded top coat facing up. Make sure it is correctly positioned at the centre of the crack.



4. Heat the Instaband using a powerful gas burner (pressure min. 3 bar). Move the flame slowly but steadily 10 to 30cm over the material in a sweeping motion so that the heat is evenly distributed. It must be heated until all the material is liquid (approx 200°C).

Sufficient heat has been applied once it starts to bubble, the edges of the material have settled down against the road surface and the individual pieces have fused together into one marking.



5. Instaband ECO will cool and harden within 5-10 minutes. Once cooled, inspect for correct installation by trying to lift it with a knife or chisel. If it can be lifted without evidence of asphalt on the underside, further heat must be applied.



HAPAS APPROVED

**START** **TRAFFIC**