



PARK-AID Wheel Stop Installation

Step 1

Lay PARK-AID down in desired position.

Step 2

Using a 14mm drill bit drill pilot holes in the ground through the PARK-AID.

Step 3

Remove PARK-AID and drill holes to a depth of 80mm.

Step 4

Place Plastic Rawl plugs (supplied) into drilled holes.

Step 5

Place PARK-AID back in position and bolt down into the Rawl Plugs using supplied bolts. Place plastic caps into bolts holes to complete installation.

