

# Speed Bump Installation Guide

How to install speed bumps using the Universal Cactus Fixing for Tarmac or Concrete



## Step 1

Place speed bumps in required position, the ground should be flat and any obstructions or debris should be cleared.



## Step 2

Once speed bumps are in the appropriate position, drill through fixing slots in the bump and mark ground with a 10mm drill bit.



## Step 3

Move the speed bumps and drill down to the depth of the fixing, (approx 100mm) using 16mm drill bit.



## Step 4

Once the holes have been cleaned, hammer the anchor plugs down so that they are flush with the ground.



## Step 5

Place bumps back over fixing holes and use either a 16mm nut driver or ratchet to tighten bolts until the speed bump is secured to the ground.