



Application of TexBand Overbanding Tape

These instructions must remain with the product to ensure correct installation. Extra copies are available to download at starttraffic.uk



- 1** Clean application area thoroughly by removing all sand, dirt, chemicals and oily substances.



- 2** Using a suitable propane torch, remove all moisture present (if any) and preheat the area prior to treatment.



- 3** Remove the packaging and carefully place the TexBand Tape onto the road surface with the glass coated top facing up. Position the tape as accurately over the crack for optimum performance. Cut to size.



- 4** Heat the TexBand Tape using a suitable propane torch keeping the flame approximately 20-40cm from the tape. Do not concentrate the heat in one area and heat with an even sweeping action. Heat until the tape starts bubbling and flowing into the road surface.



- 5** The TexBand Tape should cool and harden within 5-10 minutes. When cooled, examine the tape and test by trying to lift. If areas do lift, repeat step 4.