Usage guidelines

- Remove cap from Skipper™ unit by twisting the top cap anti-clockwise.
- 2 Once the cap has been removed, screw the base of the plastic frame into the new cap (with hole in it). Tighten up with a Phillips head screwdriver.





- 3 Insert A4 signage (not supplied) into flexiglass holder.
- 4 Slide the flexiglass holder into the frame.
- Position the cap (with frame) onto the Skipper[™] unit and twist clockwise until the cap lines up with the unit.

Made in the United Kingdom

