


The unit has a user selectable switch for: 'Off', 'Continuous' or 'Flashing' modes.



All Lights come with Batteries Included – *We sell replacement batteries if required.*

A security Key is provided to access the lights with your order.



Lights operate Dusk til Dawn with a daylight sensor (Photocell).

Our daylight sensors ensure that the lights turn on in low light and preserve battery during the daytime.

If your light isn't turning ON it could mean that there is already sufficient light.

If your light isn't turning OFF, it could be that there is insufficient daylight.

In an office environment, artificial light does not always provide the correct wavelengths. If the light is not turning off, take it outside in broad daylight.

To replace the batteries, use a Pozi-head screwdriver to loosen the 4xM4 screws holding the electronics in place. (please keep the washers on these screws in place when re-attaching the board to the pillars)

You can then lift the electronics out and replace the 4xD-Type batteries. Secure the electronics back onto the 4 pillars and test the operation before fastening the polycarbonate lens.

If you wish to keep the lights ALWAYS ON, then we suggest covering the D1 (photocell) on the electronics board. **Please note, this will shorten battery life.**

All components are RoHS compliant. If you have any queries please email us.