

Skipper accessories



Wall & magnetic support brackets
For attaching Skipper
Unit to walls or
magnetic surfaces



Rechargeable safety light
Multifunctional LED
warning light that is
fully rechargeable



A4 sign holder
Perfect for displaying
warnings, promotions
and messages



Wall & magnetic receiver clips
For attaching tape
end to walls or
magnetic surfaces

Skipper XS range



Skipper unit XS
A compact Skipper
unit for use without
cones or posts.
Can be used indoors
and outdoors



Suction pad holder/receiver
Attaches tape end
or Skipper XS to
high gloss surfaces
and glass



Clamp holder/receiver
Attaches tape end
or Skipper XS
to horizontal or
vertical surfaces



Cord & magnetic holder/receiver
Attaches tape end or XS
unit by wrapping cord
strap around objects or
magnetic surfaces

Skipper™

The total safety management solution

Usage guidelines



Skipper™

The total safety management solution

The Skipper unit

Top cap

This can screw off to allow the attachment of accessories such as the light and sign holder.

Tape end clip

This attaches to the next Skipper unit or accessory.

Tape

Each Skipper unit contains 9m (30ft) of tape.

Locking button

For use in windy conditions. Stops unwanted spooling of tape (tape will still retract).

Tape slot

These are the receptors for tape end clips from other Skipper units.

Screw holes

Use these to screw the Skipper unit into a permanent fixture.



IMPORTANT

Always walk the tape back into the unit to prevent it from folding within the unit

More products from Skipper

Skipper road cone ▶

This revolutionary two-piece cone includes an incorporated helix which deflects wind and adds to stability. It can also facilitate an optional weight ring, and its glass bead sleeve has greater reflectivity than other cones.



Skipper post & base system ▶

The Skipper Post's great versatility allows it to be used on both hard and soft ground, indoors and outdoors. The unique, interchangeable base allows it to be sunk into the ground with a spike or attached to its sturdy base for use on hard surfaces.



Available in green, silver, red, orange and blue.

Using your Skipper units

Avoid damage, improve lifespan and get the most out of the total safety management solution.

INCORRECT USE



DO NOT allow the tape end to retract on its own. Walk it back into the unit



DO NOT retract or pull tape with lock on. This will cause premature unit failure



DO NOT immerse the unit in water



DO NOT crease the tape or allow the unit to become contaminated

CORRECT USE



Click the Skipper unit on top of the cone or post



Pull the tape out to the desired length



Click the tape into the next Skipper unit or receiver



Then pull out the tape from the next unit

FEATURES



Use the clip to attach to other Skipper units or accessories



Tape can wrap around an object and attach to itself



Use screw fitting for permanent fixture



Each Skipper unit has multi-point connectivity

IMPORTANT NOTICE

Tape may be prone to fading if left in direct sunlight for very long periods.

To maximise unit life it is VERY IMPORTANT to observe the guidelines above. Failure to do so could seriously affect the performance of the Skipper unit and risk invalidating the guarantee.